


Turning your Tablet ON

1. Press (and hold) **Power** button. (See Picture(s) below to locate your Power button.)

Figure 1:
Generation 9
Fire Tablet
Controls



Figure 2:
Generation 11
Fire Tablet
Controls



2. **Release Power** when you hear the Amazon theme sound.
3. **The first screen you see after turning your tablet on may be an advertisement.** Press and swipe up from the bottom.


Figure 3
Removing
Ads from
Screen



Three Pages:

For You:

Recommendations for books, videos, apps, etc.



Home: Find and organize all your apps here. We recommend using this page as your homebase.

Library: Easily access your purchased and downloaded content on one page

Three Control Buttons:

The Triangle: Gets you back a page

The Circle: Press this to get back to your "Home" page which is your homebase for everything.



Figure 4 Getting to Home Page

The Square: "Tiles" all the program pages you've opened. To close one program at a time, **press** and **drag** them **off the screen**. This will save memory and your battery.